TECHNICAL DATA SHEET



RAKAM

401 - RAK ACRYSEAL

(ACRYLIC SEALANT)

APPLICATION

RAK ACRYSEAL is a permanent, flexible sealant for a wide variety of internal applications where low (+/-5%) movement is anticipated. Excellent adhesion to most substrates.

PROPERTIES

RAK ACRYSEAL, Acrylic Flexible Filler is a non staining, sealant that resists cracking and gives a smooth finish that requires no sanding

USES

Ideal for caulking and sealing: Door and window frames •Skirting Boards

• Floorboards • Walls

•Ceilings •Plasterboards

ADHERES TO:-

- Brick
 Concrete
 Plastic
 Ceramics
- Tiles

TYPICAL PROPERTIES

Application temperature +7°C to 40"C Working time 10 to 20 minutes Complete drying time 36 hours (Depending upon the substrate) Percentage solids 78 + 2% Specific gravity 1.56 Movement joint 10°A

SURFACE PREPARATION

Ensure gaps and cracks to be filled are dry and free of grease, dirt, dust and any loose material. Fill the seam with sample amount of filler. Can be over-painted approximately two hours after application.

- Reseal container for storage and re-use. Store away from extreme heat and cold.
- Joint sizes more than 20 mm wide or 10 mm deep must be filled with backing rod as a back-up filler.
- · Do not use for below waterline applications.
- Do not use as a putty. Do not apply when temperature is below 7°C



CLEANING

Clean tools with soap and water after use.

SHELF LIFE

Up to 8 months in unopened packs stored under 30°C. kept out of direct sunlight

CAUTION

Avoid contact with eyes and skin. Only use in well-ventilated areas. Keep out of reach of children.

ORDERING GUIDE

PRODUCT NO.	401
STANDARDS	ASTM C733
PACKAGING	5 / 20 kg Packs
COLOR	White / Grey

HEALTH AND SAFETY

As with all chemical products, caution should always be exercised. Protective clothing, such as gloves and goggles, should be worn (see packaging for specific instructions). Treat any splashes to the skin or eyes with fresh water immediately. Should any of the product be accidentally swallowed, do not induce vomiting but call for medical assistance immediately. Ensure the container is available for the medical attendant to examine any relevant instructions and contents details. Reseal all containers after use and ensure product is stored as instructed on the safety section of the labelling.